



ALCAD

ALIMENTADORES
POWER SUPPLIES
ALIMENTATIONS




SERIE 913 SERIES

CODIGO-CODE-CODE		9130054	9130057
MODELO-MODEL-MODELE		FU-612	FU-513
Tensión de salida Output voltage Tension de sortie	V ---	18	7,5
	mA	2000 (In continuous operation)	3840 (In continuous operation)
Tensión de red Mains voltage Tension du secteur	V \sim	230 \pm 15%	240 $^{+10\%}$ $^{-18\%}$ 50/60 Hz
	VA	105	95
Temperatura en proximidad del equipo Operating temperature close to equipment Température en proximité de l'équipement	°C	-10..+65	
Temperatura ambiente con/sin ventilador Room temperature with/without fan Température ambiante avec ou sans ventilateur	°C	-10..+55/+45	
Índice de protección Protection index Indice de protection		IP 20	

Protegido contra cortocircuitos
Protected against short-circuits
Protégée contre les court-circuits


CÓMO FIJAR LOS ALIMENTADORES HOW TO FIX THE POWER SUPPLIES COMMENT FIXER LES ALIMENTATIONS



CÓMO SUSTITUIR EL FUSIBLE

REPLACING THE FUSE





REPLACER LE FUSIBLE



CÓMO ALIMENTAR LAS LNB Y UN SISTEMA EN CASCAIDA

HOW TO FEED THE LNB AND A CASCADABLE SYSTEM

COMMENT ALIMENTER LES LNB ET UN SYSTÈME CASCADABLE



Especificaciones sujetas a modificación sin previo aviso
Specifications subject to modifications without prior notice
Les spécifications sont soumises à de possible modifications sans avis préalable



ALCAD Electronics, S.L.

Pol. Ind. Arreche-Ugalde, 1
Apdo. 455 | 20305 IRUN - Spain
Tel. (+34) 943 63 96 60
info@alcad.net