



Install the Smart Card Reader software

- Download the OC/SC drivers from the following link <http://support.gemalto.com/> and follow the instructions

Connecting your Smart Card Reader to your computer

- Plug the smart card reader into an available USB port.
The reader is ready for use.